



Troubleshooting and Repair Instructions

Eberspächer

J. Eberspächer GmbH & Co. KG Eberspächerstr. 24 D-73730Esslingen

Phone (switchboard) (0711)939-00 Fax (0711)939-0500

www.eberspaecher.com

The troubleshooting and repair instructions are only applicable to the following unit versions

AIRTRONIC L engine-independent air heater for petrol engines

Heater

AIRTRONIC L – B5, 12 volt

Order No.

20 1859 05 00 00

for diesel engines

Heater

Order No.

AIRTRONIC L – D5, 12 volt

25 2361 05 00 00

AIRTRONIC L - D5, 24 volt

AIRTRONIC L engine-independent air heater

25 2362 05 00 00



Introduction

List of Contents

This list of contents gives you precise information about the contents of the Troubleshooting and Repair Instructions.

If you are looking for a term, technical term or you would like an abbreviation explained, please use the relevant index at the end of the instructions, from Page 44.

Chapter	Title	Contents	Page
1 Introdu	Introduction	Contents Foreword Safety instructions for installation and repair Accident prevention Special text structure, presentation and picture symbols	
2	Function	Cutaway view Functional description Control and safety devices Forced shutdown ADR / ADR99 Emergency stop (EMERGENCY OFF)	
3	Product information	Technical data AIRTRONIC L – petrol / diesel Table of values: "External temperature sensor"	8
4	Troubleshooting	What to check first in case of faults Locking the control box Cancel the control box lock Check control unit Overview of testing equipment Diagnostic unit Module timer – installed in the vehicle KD2000 Customer service program TP5 radio remote control. Fault diagnosis using the diagnostic unit Fault diagnosis using the module timer Fault diagnosis using the customer service program KD2000 Fault diagnosis using the radio remote control TP5 Fault code table	91011111112, 1314, 15161718 – 22
5	Repair instructions	Repair instructions Always observe the following safety instructions before working on the heater Special tool AMP release tool Assembly drawing Parts list Repair step 1 Dismantle / assemble glow plug Repair step 2 Dismantle / assemble lining Repair step 3 Dismantle / assemble control box Repair step 4 Dismantle / assembly combination sensor (overheating / flame secheck combination sensor Repair step 5 Dismantle / assemble combustion air fan Repair step 6 Replace the combustion chamber cover seal Check fuel supply Measuring the fuel quantity	



Introduction

List of Contents

Chapter	Title	Contents	Page
6	Circuit diagram	Parts list AIRTRONIC L - 12 volt / 24 volt Parts list AIRTRONIC L - ADR / ADR99 - 12 volt / 24 volt Circuit diagram AIRTRONIC L - 12 volt / 24 volt Circuit diagram for control units Circuit diagram AIRTRONIC L - ADR / ADR99 - 12 volt / 24 volt Circuit diagram control units - ADR / ADR99	32 33 34 – 38
7	Service	Certifications Disposal EC Declaration of Conformity Representatives abroad	4
8	Index	Index List of abbreviations	42

Introduction

Foreword

These Troubleshooting and Repair Instructions are applicable to the heaters listed on the title page, to the exclusion of all liability claims.

Depending on the version or revised status of the heater, there may be differences between it and these troubleshooting and repair instructions.

The user must check this before carrying out the repair work and, if necessary, take the differences into account.



Caution!

Safety instructions for installation and repair!

Improper installation or repair of Eberspächer heaters can cause a fire or result poisonous exhaust entering the inside of the vehicle. This can cause serious and even fatal risks.

The heater may only be installed according to the specifications in the technical documents or repaired using original spare parts by authorised and trained persons. Installation and repairs by unauthorised and untrained persons, repairs using non-original spare parts and without the technical documents required for installation and repair are dangerous and therefore are not permitted.

A repair may only be carried out in connection with the respective unit-related technical description, installation instructions, operating instructions and maintenance instructions. This document must be carefully read through before / during installation and repair and followed throughout. Particular attention is to be paid to the official regulations, the safety instructions and the general information.

Please note!

The relevant rules of sound engineering practice and any information provided by the vehicle manufacturer are to be observed during the installation and repair.

Eberspächer does not accept any liability for defects and damage, which are due to installation or repair by unauthorised and untrained persons.

Compliance with the official regulations and the safety instructions is prerequisite for liability claims. Failure to comply with the official regulations and safety instructions leads to exclusion of any liability of the heater manufacturer.

Accident prevention

General accident prevention regulations and the corresponding workshop and operating safety instructions are to be observed.

Special text structure, presentation and picture symbols

Special text formats and picture symbols are used in these instructions to emphasise different situations and subjects. Please refer to the following examples for their meanings and appropriate action.

Special text formats and presentations

- A dot (•) indicates a list, which is started by a heading.
- If an indented dash (-) follows a "dot", this list is a subsection of the black dot.

Picture symbols



Danger!

This information points out a potential serious or fatal danger. Ignoring this information can result in severe injuries.




Caution!

This information points out a dangerous situation for a person and / or the product. Ignoring this information can result in injuries to people and / or damage to machinery.

2 Function



Cutaway view



- 1 Module timer
- 2 Changeover switch "heat / ventilate"
- 3 Fuse bracket
 - Main fuse 25 A
 - Fuse, "actuation" 15 A
- 4 Heater impeller
- 5 Control box
- 6 Intake hood
- 7 Combustion air fan
- 8 Glow plug
- 9 Jacket shell, top
- 10 Combination sensor (overheating and flame sensor)
- 11 Outlet hood
- 12 Outflow
- 13 Safety grille
- 14 Electrical motor
- 15 Combustion air intake silencer

- 16 Fuel connection
- 17 Combustion chamber
- 18 Flame pipe
- 19 Heat exchanger
- 20 Jacket shell, bottom
- 21 Metering pump
- 22 Pot-type strainer
- 23 T-piece
- 24 Exhaust pipe
- F = Fresh air
- W = Hot air
- V = Combustion air
 - A = Exhaust
 - B = Fuel

2 Function

Description of functions

Switching on / starting the heater

When the heater is switched on, the control lamp in the control unit lights up.

The fan starts up in the fan stage "LOW". The glow plug starts with a 3 second delay. After approx. 45 seconds the fuel supply starts and the fuel / air mixture in the combustion chamber ignites.

The fan switches from fan stage "LOW" to fan stage "MEDI-UM". The glow plug is switched off after 165 seconds, when a stable flame has formed.

The fan switches from fan stage "MEDIUM" to fan stage "HIGH".

The heater is run at an increased heating capacity of 5.5 kW in order to quickly reach the heater's operating temperature. If the heater's operating temperature has been reached, the heating capacity is reduced to 4.8kW. The length of time for which the heater is run with an increased heating output depends on the ambient temperature.

Control in heating mode

If the intake or ambient temperature set at the control device (10 °C up to 30 °C) has been reached, the heater switches to the "LOW" control level and then continues to run with a low fan motor speed.

If the heat flow at the "LOW" control level of 1.2 kW or 2.0 kW is insufficient, the heater switches to the "MEDIUM" control level. The fan continues to run at a low speed. In most cases the "LOW – MEDIUM – LOW" control at a low speed will cover the heating requirements.

If the heat flow at the "MEDIUM" control level is insufficient, the heater switches back to the "HIGH" control level. This in turn requires the full fan motor speed.

If, in special cases, even less heat flow is required than supplied by the heater at the "LOW" control level, the heater switches to "OFF".

The fan then continues to run for approx. 4-5 minutes and, only in recirculation mode, constantly ventilates until it is restarted. The restart takes place at the "MEDIUM" control level at a low fan motor speed.

Ventilation mode

If the heater is set to "Ventilation" at the control element, the fan runs at maximum speed.

Switching off

When the heater is switched off, the control lamp goes out and the fuel delivery is switched off.

The fan continues to run for approx. 4-5 minutes to cool down.

2 Function



Control and safety devices

- If the heater does not ignite within 90 seconds after the fuel starts to pump, the start is repeated. If the heater still does not ignite after another 90 seconds of pumping fuel, the heater is switched off, i.e. the fuel supply is off and the fan runs on for approx. 4 5 minutes. After an unacceptable number of failed start attempts, the control box is locked.*
- If the flame goes off by itself during operation, the heater is restarted. If the heater does not ignite within 90 seconds after the fuel pump has restarted, or ignites and goes off again within 15 minutes, the heater is switched off, i.e. the fuel supply is off and the fan runs on for approx. 4 5 minutes. This automatic switching off can be cancelled by briefly switching off and on again. Do not repeat the switching off / on routine more than twice.
- In the case of overheating, the combined sensor (flame sensor / overheating sensor) triggers, the fuel feed is interrupted and the heater switched off. Once the cause of the overheating has been eliminated, the heater can be restarted by switching off and on again. After an unacceptable number of failed start attempts, the control box is locked.*
- If the lower or upper voltage limit is reached, the heater is switched off after 20 seconds.
- The heater will not start if the glow plug or blower motor is defective or if the electric lead to the metering pump is interrupted.
- If the combined sensor (flame sensor / overheating sensor) is defect or the electric lead interrupted, the heater starts up and is then switched off again during the start phase.
- The speed of the blower motor is continuously monitored. If the blower motor does not start up or if the speed deviates by more than 10 %, the heater is switched off after 30 sec.
- When the heater is switched off, the glow plug is switched on for 40 seconds (after glowing) while the fan runs on, in order to clean off any combustion residues.
- * The lock can be cancelled and faults read out:
 - · using the module timer
 - with the radio remote control TP5. For other control units by connecting:
 - · the diagnostic unit
 - the customer service program KD2000.
 For operation and fault list, please refer to the enclosed operating instructions for the control units and test equipment or these troubleshooting and repair instructions from Page 11 22.

Please note!

Do not repeat the switching off / on routine more than twice.

Forced shut-down for ADR / ADR99 operation

In vehicles for the transport of dangerous goods (e.g. tanker trucks), the heater must be switched off before the truck drives into a danger area (refinery, petrol station, etc.). Failure to comply results in the heater switching off automatically when:

- The vehicle engine is switched off.
- An additional unit is switched on (auxiliary drive for unloading pump, etc.)
- A vehicle door is opened (ADR99 regulation, only in France). The fan then runs on for max. 40 seconds.

Emergency stop - EMERGENCY OFF

If an emergency stop – EMERGENCY OFF – is necessary during operation, proceed as follows:

- · Switch the heater off at the control unit or
- · pull the fuse out or
- disconnect the heater from the battery.

Product information

Technical data


Heater		AIRTRONIC L – B5				AIRTRONIC L - D5					
Heating medium		Air				Air					
Control of the heat flow				Sta	age					Stage	
		Power	Hig	gh	Medium	n l	Low	Power	High	Medium	Low
Heat flow (watt)		5500	480	00	2700	1	1200	5500	4800	2700	1200
Heater air flow rate without counterp	oressure (kg/h)	280	27	'5	180		125	280	275	180	125
Heater code				1	0					10	
Fuel consumption (I/h)		0.75	0.6	65	0.37	(0.27	0.66	0.58	0.34	0.15
Elect. power consumption (watt)	in operation	85	80	0	30		15	85	80	30	15
	while starting			< 2	250					< 250	
Rated voltage (volt)				1	2				1	2 / 24	
Operating range Lower voltage limit: An undervoltage protection installed in the control box switches off the heater at approx. 10 volts and 20 volts respectively.		approx. 10 volt and 20 volt respectively Undervoltage protection trigger time: 20 seconds									
Upper voltage limit: An overvoltage protection installed in the control box switches off the heater at approx. 14 volts and 28 volts respectively.		approx. 14 volt and approx. 28 volt respectively Overvoltage protection trigger time: 20 seconds									
Fuel		Petrol – standard commercial quality Diesel fuel – standard comme (DIN EN 51600 / DIN EN 228) quality (DIN EN 590)									
Permissible ambient temperature		Heater			ntrol		tering ump	Heate	er	Control box	Metering pump
	Operation	-40 °C + +50 °C		-40 ° +75	°C to		°C to	-40 °C +70 °		40 °C to +75 °C	-40 °C to +50 °C
	Storage	-40 °C 1 +85 °C		-40 ° +85	°C to		°C to 35 °C	-40 °C +85 °	- 1	40 °C to +85 °C	−40 °C to +85 °C
Noise emission – passenger compartment		The maximum noise pressure level is <64 db (A), measured in the operating mode power stage "High", as per 3. GSGV and DIN 45 635 – part 1 resp.									
Maximum air intake temperature		+40 °C									
Interference suppression		Suppression class 5 to DIN 55025									
		approx. 9.3 kg									
							Pos	sible			



Caution! Safety instructions for technical data!
Failure to comply with the technical data can result in malfunctions.

Check "external temperature sensor"

The external temperature sensor must be checked with a digital multimeter. Replace the overheating or flame sensor if the resistance value is not the same as the curve in the diagram or the table of values.



All technical data ± 10 %

Table of values: "External temperature sensor"

Temp. °C	Resistance Ω	min.	max.
0		1600	1660
5		1670	1730
10		1745	1800
15		1820	1870
20		1895	1950
25		1970	2030
30		2050	2110
35		2130	2190
40		2210	2280
45		2295	2370





What to check first in case of faults

· Check whether:

- Fuel in the tank?
- Fuel pipes leaking? (visual check)
- Summer diesel still in the fuel pipe?
- Combustion air system or exhaust system damaged or blocked?

Electrical components:

- Cables, connections damaged?
- Contacts corroded?
- Fuses defective?
- Incorrect wiring? (short circuits, interrupted / broken)

· Check battery voltage

- Battery voltage < 10 volt, the undervoltage protection of the 12 volt heater has triggered.
- Battery voltage < 20 volt, the undervoltage protection of the 24 volt heater has triggered.

Check voltage supply U_{Batt} (terminal 30)

Disconnect the 16-pin connector S1 / B1 and measure the voltage applied at connector B1 between chamber 1 (cable 2.5² rt) and chamber 10 (cable 2.5² br). If it differs from the battery voltage, check the fuses, the supply cables, the negative connection and the positive support point on the battery for voltage drop (corrosion / interruption).

Check switch-on signal (S+)

Disconnect the 16-pin connector S1 / B1 and then press the button $\boxed{\mbox{$1$}}$ at the control unit.

Measure the applied voltage in connector B1 between chamber 4 (cable 0.5^2 ge) and chamber 10 (cable 2.5^2 br). If no voltage is measured, then check the supply cable (cable 0.5^2 ge), the 5 A fuse (item 2.7.1 in the circuit diagram) and the control unit.

• Check the control unit (module time / mini timer)

Disconnect the connector at the control unit, jumper between the red 0.5^2 cable and the yellow 0.5^2 cable. If a voltage is measured in connector B1 between chamber 7 (cable 0.5^2 ge) and chamber 2 (cable 2.5^2 br), then replace the control unit.

Locking the control box

The control box is locked if the following faults occur:

· Too many attempted starts

If the heater carries out several consecutive failed started attempts – fault code 050 is displayed –> the control box is locked.

Overheating

If the heater overheats several times consecutively – fault code 015 is displayed –> the control box is locked.

Cancel the control box lock

Cancellation of the control box lock depends on the appropriate test equipment and is described on Pages 13, 15, 16 and 17.


Check control unit

Order No. for the testing device – control unit – 22 1509 89 00 00

Before the test

Connect the correct operating voltage (12 or 24 volt) to the testing device, with plus at the red connector socket and minus at the blue connector socket.

- Disconnect socket from the control unit.
- Connect cable loom from testing device with the control unit.
- Set the rotary knob of the control unit to "Heat", the corresponding red LED in the testing device must light up.
- Set control unit to "O", then press the "LED red" button, the red control lamp in the control unit must light up.
- Set control unit to "Heat", then press the "LED green" button, corresponding red control lamp in the testing device and the green control lamp in the control unit must light up.





Caution!

Operating voltage safety information!


Ensure you use the correct operating voltage, otherwise the connected components can be severely damaged.

Check the setpoint potentiometer of the control unit

Set the "Temperature sensor / Potentiometer" switch in the testing device to the "Potentiometer" setting and slowly turn the rotary knob of the control unit.

The green LED – temperature sensor / potentiometer must light up continuously.

In case of a fault, replace the control unit.





Overview of testing equipment

The heater's electronic control box can store up to 5 faults. The faults can be read out of the control box and displayed using one of the following devices. In addition, it is possible to cancel the control box lock.

Diagnostic unit

After connecting the diagnostic unit the function or fault are shown as a number in the display.

For details of connecting and operating the diagnostic unit see Page 12 and 13.


An adapter cable is required to connect the diagnostic unit. For fault code table, see Pages 18 to 22.

• Module timer - installed in the vehicle

The installed module timer can be used to show the function or fault as a number in the display.


For fault diagnosis using the module timer see Pages 14 and 15.

For fault code table, see Pages 18 to 22.



Order No. Diagnostic unit Adapter cable

22 1529 89 00 00 22 1000 31 86 00



Order No. Module timer

22 1000 30 34 00

KD2000 Customer service program

After installing the customer service program KD2000 and connecting the ISO adapter the function or fault are displayed on the screen as a number. For connection and operation of the ISO adapter see Page 16. An adapter cable is required to connect the ISO adapter.


For fault code table, see Pages 18 to 22.

• TP5 radio remote control

The radio remote control TP5 can be used to show the function or fault as a number in the display.

For operation of the TP5 radio remote control see Page 17.

For fault code table, see Pages 18 to 22.



Order No. ISO adapter Adapter cable

22 1524 89 00 00 22 1000 31 86 00



TP5 radio remote control

22 1000 32 01 00

Fault diagnosis using the diagnostic unit

Diagnostic unit Order No. 22 1529 89 00 00

An adapter cable is required to connect the diagnostic unit.

Adapter cable Order No. 22 1000 31 86 00

Connect diagnostic unit

- Disconnect the 16-pin connector of the heater's cable harness and connect the adapter cable.
- The connect the diagnostic unit to the adapter cable.

After the adapter cable and diagnostic unit have been connected the following appears in the display.



Please note!

It is very important to always install in the given order. Fault code, fault description, cause / remedial action are described on Pages 18 to 22.

Enquire fault memory

The current fault is displayed as "AF" and a 2-digit number and is always written in the memory location F1. Preceding faults are moved to the memory locations F2 – F5, if necessary the content of F5 is overwritten.

Press button D -> the heater is switched on.
 Display is as follows:




• After 8 sec. the following appears in the display:

RF:00 % No fault

or




or



Possible causes:

- Adapter cable is not properly connected.
- Control box is defective or not diagnosable (not a universal control box).



- L button Delete fault memory
- Dutton Delete fault memory
- (3) D button Switch heater on / off, request diagnosis
- ④ button –Reverse, fault F5 F1, AF
- ⑤ button –Forward, fault AF, F1 F5
- 6 Display

Display of the fault memory F1 - F5 or F5 - F1

- The heater is switched on.
- Press the buttons and once or several times to display the individual fault memory positions, in ascending or descending order.

Display is as follows:

F2: IDe.g. fault memory 2 / fault code 10

Only the fault memory positions with an error code assigned to them are displayed.

Delete fault memory

- · Correct cause of fault.
- Press button D -> the heater is switched on.
- Press both keys simultaneously until the following appears in the display:




If all the fault memory positions have been deleted the most recent fault is displayed. The most recent fault is not reset to 00 until the heater is restarted.

Display is as follows:

RF:00 M Heater has no malfunction

If a new, most recent fault exists it is displayed.






Cancel the control box lock

- Delete the fault memory as described and switch off the heater using the D button.
- The control box lock is cancelled and the diagnosis closed. Display is as follows:



Please note!

Not only the defective component, but also a defective current circuit results in a fault being displayed.



- Heater
- Adapter cable
- 3 Diagnostic unit

Fault diagnosis using the module timer

Module timer Order No. 22 1000 30 34 00

Start diagnosis

The heater must be switched off before the diagnosis is started.

Please note!

Fault code, fault description, cause / remedial action are described on Pages 18 to 22.

Enquire fault memory

The current fault is displayed as "AF" and is always written in the memory position F1.

Preceding faults are moved to the memory locations F2 – F5, if necessary the content of memory position F5 is overwritten.

- Press button ② and keep it depressed, then press button
 P within 2 seconds.
 Display is as follows:


RF 54 S Current fault (AF) e.g. fault code 64

Display of the fault memory F1 - F5 or F5 - F1

- The heater is switched on.
- Press the buttons and once or several times to display the individual fault memory positions, in ascending or descending order.
 Display is as follows:

e.g. fault memory 2 / fault code 10

Only the fault memory positions with a fault code assigned to them are displayed.



- 1) D button Time
- P button Preset
- 3) W button Heat
- ④ button −Reverse
- ⑤ button –Forward
- Display fault

Delete fault memory

Condition:

An electrical connection exists from terminal 15 (ignition) to the module timer, 12-pin connector, chamber 10.

- · Correct cause of fault.
- Press button W -> The heater is switched on.
- Press button ①, keep it depressed and then press button
 P within 2 seconds.

The module timer is now in the "Enquire fault memory" program.

- Switch off ignition (terminal 15).
- Simultaneously press button (2) and button (P), in addition, switch on the ignition (terminal 15) and wait until the following appears in the display.

After ignition "ON" the following appears in the display:


Display flashes, heater symbol does not flash

 Switch the heater off and on -> the control box is unlocked, the heater restarts.

If all the fault memory positions have been deleted the most recent fault is displayed. The most recent fault is not reset to 00 until the heater is restarted. Display is as follows:

RF 00 15 Heater has no malfunction

If a new, most recent fault exists it is displayed.





Cancel the control box lock

- Delete the fault memory as described and switch the heater on and off using the button.
- The control box lock is cancelled and the diagnosis closed.
 After switching the heater off and on and re-enquiring the fault memory the following appears in the display:



Display flashes, heater symbol does not flash

Please note!

Not only the defective component, but also a defective current circuit results in a fault being displayed.

Fault diagnosis using the customer service program KD2000

KD2000 Customer service program Order No. 22 1524 89 00 00

An adapter cable is required to connect the ISO adapter.

Order No. 22 1000 31 86 00

Connect ISO adapter

- Disconnect the heater's cable harness.
- Connect the adapter cable to the cable harness as shown in the sketch.
- Connect the adapter cable to the ISO adapter.
- Connect the SUB-D connection cable with the PC and the ISO adapter.

Please note!

It is very important to always install in the given order.

Fault code, fault description, cause / remedial action are described on Pages 18 to 22.

Install KD2000 software on the PC


- Place the CD-ROM in the CD-ROM drive.
- To start, double click the "setup.exe" file and follow the SETUP program instructions.

Enquire / delete fault memory F1 – F5 or cancel the control box lock

- Start the KD2000 software at the PC:
 - On the desktop
 - -> Double click the "KD2000" icon.
- Select heater type.
- Press the "GO" button.
- Delete fault memory or cancel the control box lock:
 - Press the "Delete fault memory" button
 - -> the stored faults F1 F5 are deleted and the control box is unlocked.

Quit diagnosis

• Press the "STOP" button -> fault memory enquiry is ended.



- Heater
- Adapter cable

- (3) ISO adapter
- (4) SUB-D connection cable



Fault diagnosis using the radio remote control TP5

TP5 radio remote control Order No. 22 1000 32 01 00

If faults occur while the heater is running, they are displayed with "Err" after the mobile unit is activated.

Please note!

In order to carry out the diagnosis, the diagnosis cable (blue / white) must be connected to the stationary unit and the heater cable harness. To this end, please refer to and follow the circuit diagram for the TP5 radio remote control and the heater.

If the diagnosis cable (blue / white) is not connected, the "Diagnosis" menu is blocked.

After the diagnosis cable (blue / white) has been connected and the first logs have arrived at the stationary unit, the diagnose can be carried out using the mobile unit of the TP5 radio remote control.


The current fault "F0" is displayed. The stored faults "F1" to "F5" can be enquired.

Correct the fault according to these troubleshooting and repair instructions.

Example:

- F0 -- = undisturbed operation
- F011 = current fault 11
- F110 = Fault 10 stored in fault memory position 1 (F1).

Fault code, fault description, cause / remedial action are described on Pages 18 to 22.



- (b) Button to activate / deactivate the mobile unit
- Button for forward time setting
- Button for backward time setting
- P Button for activating the possible settings
- Button for switching heat / ventilate ON / OFF; Activate / deactivate preselected time

Enquire / delete fault memory

Use the **(b)** button to activate the mobile unit.

Switch on the heater with the (**) button.

Press the P button twice to open the Time setting menu – the time flashes in the display.



Press the P button for approx. 2 sec – until the following appears in the display:



Press (**) button.

Press P button.

Press (**) button twice.

Press P button.

Malfunction in heater:

Heater has no malfunction:



FO --« •• Use the
and
buttons to call up the fault memory positions 1 to 5.



Delete fault memory / cancel the control box lock

Use the P button to delete the fault memory.



To confirm, press the $\boxed{\bot}$ button for approx. 2 sec until the following appears in the display:



Fault memory is deleted.

Please note!

If the fault memory is to be deleted later, the whole procedure must be repeated.

Fault code Display	Fault description	Comments • Remedial action		
000	No faults	_		
004	Warning: Short circuit in control box, fresh air output	 Disconnect connector S1 / B1 at the heater and at the connector B1, PIN 16 check the cable up to the fresh air fan relay for short circuit to negative, if ok -> replace control box, see Page 26. 		
(005)	Warning: Short circuit in control box, car alarm output	Disconnect connector S1 / B1 at the heater and at the connector B1, PIN 15 check the cable up to the relay isolating switch or the car alarm input for short circuit to negative, if ok -> replace control box, see Page 26.		
009	Cutout ADR / ADR99	ADR / ADR99 shutdown due to signal change from (+) to (-) at connector S1, PIN 13 (D+) or plus signal at connector S1, PIN 14 (HA+).		
010	Overvoltage cutout	Overvoltage applied to control box for at least 20 seconds without interruption – heater not working. • Disconnect connector S1 / B1 at the heater, start the vehicle's engine, measure the voltage at connector B1 between PIN 1 (cable 2.5² rt) and PIN 10 (cable 2.5² br).		
011	Undervoltage cutout	 Undervoltage applied to control box for at least 20 seconds without interruption – heater not working. Disconnect connector S1 / B1 at the heater, the vehicle's engine is switched off, measure the voltage at connector B1 between PIN 1 (cable 2.5² rt) and PIN 10 (cable 2.5² br). The measured value and the voltage at the battery should be the same. In case of a voltage drop, check the fuses, the supply cables, the negative connections and the positive support point on the battery for corrosion and correct contact. 		
012	Overheating at the overheating sensor	 Temperature of the overheating sensor too high. Check hot air pipes for blockage -> remove blockage. Sum of the component ratings of air-conducting parts is too large -> Check air system, if necessary re-lay - for component ratings, please refer to additional parts catalogue. Check overheating sensor, for diagram and table of values please refer to Page 28, if ok -> measure fuel quantity, see Page 31. 		
013	Overheating at the flame sensor	 Flame sensor signals temperature at heat exchanger is too high. Check hot air pipes for blockage -> remove blockage. Sum of the component ratings of air-conducting parts is too large -> Check air system, if necessary re-lay - for component ratings, please refer to additional parts catalogue. Check flame sensor, if ok -> check overheating sensor, if overheating sensor defective -> replace combination sensor, if overheating sensor ok -> measure fuel quantity, see p. 31, for diagram and table of values for flame sensor and overheating sensor please refer to Page 28. 		
014)	Temperature difference between flame sensor and overheating sensor too large	 Temperature difference between flame sensor and overheating sensor too large Check hot air pipes for blockage -> remove blockage. Sum of the component ratings of air-conducting parts is too large -> Check air system, if necessary re-lay - for component ratings, please refer to additional parts catalogue. Check flame sensor, if ok -> check overheating sensor, if overheating sensor defective -> replace combination sensor, if overheating sensor ok -> measure fuel quantity, see Page 31, if fuel quantity ok -> replace control box, see Page 26. For diagram and table of values for flame sensor and overheating sensor see Page 28. 		



Fault description	Comments • Remedial action
Operating lock-out	The fault code 015 is displayed, if the heater was switched back on after the fault code display 017. The hardware threshold value for the overheating sensor has been exceeded -> the control box is locked. • Switch off control box, see Page 26.
Overheating	The hardware threshold value for the overheating sensor has been exceeded, because the control box failed to recognise the fault code 012 or 013 -> the control box is locked. If the heater is switched on again, the fault code 015 is displayed. Switch off control box, see Page 26.
Glow plug – interruption	• Check glow plug is working and for continuity. 12 volt heater – approx. 0.5 Ω ± 0.05 Ω 24 volt heater – approx. 2 Ω ± 0.2 Ω
Glow plug output - short circuit, overload or earth short	If the values of the continuity test and functional test are ok -> check the glow plug's lead harness for damage and continuity, if ok -> replace control box, see Page 26.
Glow plug output defective	Check whether supply lead to these components has a short circuit after +Ub, if no -> check components for earth short, if necessary replace control box, see Page 26.
K line short circuit	Check diagnostic cable PIN 0.5 ² bl / ge for damage.
EMK blower motor outside the permissible range	 Impeller or combustion air blower motor blocked (frozen, soiled, sluggish, lead harness grinds against shaft end) Remove blockage. Speed measurement of the combustion air blower motor: – Dismantle combustion air fan, see Page 29. Carry out test with 8.2 volt +0.2 volt, to do this unclip the 0.75² black cable from chamber 13 of the 16-pin connector and the 0.75² brown cable from chamber 14. Apply marking (white paint) to the impeller and measure the speed using a non-contact r.p.m. counter: If the measured speed in the "high" heating level is outside the range 4800*200 rpm, then replace the combustion air fan, see Page 29. If the measured speed in the "high" heating level is within the range 4800*200 rpm, then replace the control box, see Page 26.
Blower motor interruption	 Check that the lead harness of the blower motor has been correctly laid and for damage, if ok -> remove lead harness at control box and check for conti- nuity, if ok -> replace control box, see Page 26.
Blower motor short circuit Please note! In the 12 volt heater, carry out the functional check with max. 8 volt. In the 24 volt heater, carry out the functional check with max. 18 volt. The component is destroyed if the voltage values are exceeded. Ensure the power pack has adequate short-circuit resistance – min. 20 A.	 Carry out functional test on the blower motor, to do this remove the connector from the control box. Apply a voltage of 8 v or 18 V ±0.1 v to the blower motor and after 40 sec measure the current intensity. Current intensity < 6.5 A – blower motor ok –> replace control box, see Page 26. Current intensity > 6.5 A –> replace combustion air fan, see Page 29.
	Operating lock-out Overheating Glow plug – interruption Glow plug output – short circuit, overload or earth short Glow plug output defective K line short circuit EMK blower motor outside the permissible range Blower motor short circuit Please note! In the 12 volt heater, carry out the functional check with max. 8 volt. In the 24 volt heater, carry out the functional check with max. 18 volt. The component is destroyed if the voltage values are exceeded. Ensure the power pack has adequate short-circuit

Fault code Display	Fault description	Comments • Remedial action		
034	Burner motor output defective	 Check whether the supply lead to these components has a short circuit after GND, if no -> check components for earth short, if necessary replace control box, see Page 26. 		
047)	Metering pump short circuit or overload	 Remove connector from the metering pump, if the fault code 048 (interruption is displayed the metering pump is defective -> replace metering pump. If the fault code 047 continues to be displayed, disconnect connector S1 / B at the heater, and at the connector B1, PIN 5 check the cable 12 gn / rt up to the metering pump for short circuit to negative (PIN 10), if ok -> replace control box, see Page 26. 		
048	Metering pump interruption	 Remove connector from the metering pump and measure the resistance value of the metering pump (12 V = 10 Ω ±0.5 Ω / 24 V = 36 Ω ±1.8 Ω), if resistance value ok -> reconnect cable loom to the metering pump. Disconnect connector S1 / B1 at the heater and measure the resistance value between PIN 5 and PIN 10, if ok -> replace control box, see Page 26. 		
049	Metering pump short circuit after +Ub	 Check whether supply lead to these components has a short circuit after +Ub, if no -> check components for earth short, if necessary replace control box, see Page 26. 		
050	Too many failed start attempts (operating lock-out)	The control box locks after too many failed start attempts (max. 255 start attempts). • Unlock the control box by deleting the fault memory using the time, the diagnostic unit, the customer service program KD2000 or the TP5 remote control, see Page 13, 15, 16 or 17.		
051)	Flame detected when switching on	 If, after being switched on, the resistance value of the flame sensor is 1274 Ω (> 70 °C) the heater's fan rungs for approx. 15 min to cool down, if the resistan does not fall below the aforementioned value within 15 min the heater is switch off. Check the flame sensor, for diagram and table of values please refer to Pag 28, if ok -> replace control box, see Page 26. 		
052	Safety time exceeded	No flame detected during the start phase. Check exhaust and combustion air system. Check fuel supply / measure fuel quantity, see Page 31. Check spark plug (see fault code 020 and 021). Check flame sensor, for diagram and table of values please refer to Page 28, if ok -> replace control box, see Page 26.		
053 054 055 056	Flame cutout in the "HIGH" control stage "MEDIUM" control stage "LOW" control stage	The heater has ignited (flame detected) and signals flame cutout during a power stage. • Check exhaust and combustion air system. • Check fuel supply / measure fuel quantity, see Page 31. • Check flame sensor, for diagram and table of values please refer to Page 28, it ok -> replace control box, see Page 26.		
060	Interruption – external temperature sensor	 Disconnect the connector S2 / B2 of the external temperature sensor and measure the resistance value at connector B2, for diagram and table of values see Page 8, if temperature sensor ok -> reassemble connector S2 / B2. Disconnect connector S1 / B1 at the heater and measure the resistance value in connector housing B1 between PIN 6 and PIN 12. If an interruption exists the ohmic value between PIN 6 and PIN 12 > 7175 Ω. If resistance value ok -> replace control box, see Page 26. 		







Fault code Display	Fault description	Comments • Remedial action
061	Short circuit – external temperature sensor	 Disconnect connector S2 / B2 of the external temperature sensor, if error code 060 is displayed -> check external temperature sensor, for diagram and table of values, see Page 8. If temperature sensor ok -> check connection cables 0.5² gr and 0.5² br / ws for short circuit, if ok -> reassemble connector S2 / B2. Disconnect connector S1 / B1 at the heater and measure the resistance value in connector housing B1 between PIN 6 and PIN 12. If a short circuit exists the ohmic value between PIN 6 and PIN 12 < 486 Ω. If the error 061 continues to be displayed, -> replace control box, see Page 26.
062	Control unit interruption	 Remove connector at the control unit and measure the resistance value of the setpoint potentiometer, for connector pins see Page 34 to 38 and 40. If the resistance value is ok -> reconnect connector at the control unit. Disconnect connector S1 / B1 at the heater and measure the resistance value between PIN 6 and PIN 7 in the connector housing B1, if resistance value is ok -> replace control box, see Page 26. Resistance value in case of interruption between PIN 6 and PIN 7 > 7175 Ω. Normal value: 1740 Ω - 2180 Ω (±80 Ω).
063	Control unit short circuit Fault recognition only works in heating mode. If, on the other hand, the short circuit has already occurred and then the heater is switched on, "Ventilation" is active (not a fault code).	 If the "Ventilate" switch is installed, disconnect it and check it works. If not ok –> replace switch. Disconnect connector at control unit, if error code 062 is displayed, replace the control unit. If control unit ok –> check connection cables 0.5² gr / rt and 0.5² br / ws for short circuit, if ok –> reconnect connector at control unit. Disconnect connector S1 / B1 at the heater, if the error 063 continues to be displayed –> replace control box, see Page 26. Resistance value in case of short circuit between PIN 6 and PIN 7 < 486 Ω. Normal values: 1740 Ω – 2180 Ω (±80 Ω).
064	Flame sensor interruption	 Dismantle control box and disconnect green connector from control box. Check flame sensor, for diagram and table of values please refer to Page 28, if flame sensor ok -> replace control box, see Page 26. Resistance value in case of interruption > 7175 Ω.
065	Short circuit in flame sensor	 Dismantle control box, remove green connector from control box, if error 064 is displayed -> replace combination sensor, see Page 27. If error 065 continues to be displayed -> replace control box, see Page 26. Resistance value in case of short circuit < 486 Ω, see also diagram on Page 28.
071)	Overheating sensor interruption	• Dismantle control box, disconnect blue and green connectors from control box. Measure resistance value at the blue connector PIN 1 (cable 0.5^2 bl) and at the green connector PIN 2 (cable 0.5^2 br / ws), if ok -> replace control box, see Page 26. Resistance value in case of interruption >223 k Ω , see also diagram on Page 28.
	Short circuit in overheating sensor	 Dismantle control box, remove blue connector from control box, if error 071 is displayed -> replace combination sensor, see Page 27. If error 072 continues to be displayed -> replace control box, see Page 26. Resistance value in case of short circuit < 183 Ω, see also diagram on Page 28.
	Control box defective (internal fault)	Replace control box, see Page 26.
091)	External interference voltage	Control box fault due to interference voltages from the vehicle's electrical system. Possible causes: Poor battery, charger -> remove interference voltage.

Fault code Display	Fault description	Comments • Remedial action	
092	Control box defective (ROM error)	Replace control box, see Page 26.	
093	RAM error	Replace control box, see Page 26.	
094	Control box defective (EEPROM error)	Replace control box, see Page 26	
095	Software stack overrun	Replace control box, see Page 26.	
096	Internal temperature sensor defective	Replace control box, see Page 26 or use external temperature sensor.	
097	Control box defective	Replace control box, see Page 26.	
098	Main relay defective	Replace control box, see Page 26.	
099	EEPROM error	Replace control box, see Page 26.	



Repair instructions

The permitted repair work to the heater is described in the "Repair Instructions" chapter. If extensive repairs are necessary, it makes sense to dismantle the heater.

The heater is assembled in the reverse order, if applicable not additional instructions.

Please note!

After completing all the work on the heater, you must carry out a functional check.

Always observe the following safety instructions before working on the heater



Danger!

Risk of injury, burns and poisoning!

- Always switch off the heater beforehand and leave it to cool.
- · Disconnect the battery.
- The heater must not be operated in closed rooms such as garages or workshops. Exception:

Exhaust suction available directly at the entry to the exhaust



- The seals of dismantled components must be renewed.
- During repair work, check all components for damage and if necessary replace.
- Check connector contacts, plug-in connections and cables for corrosion and damage and if necessary repair.
- Only ever use Eberspächer spare parts if replacements are necessary.
- After working on the coolant circuit the level of the coolant must be checked and if necessary topped up according to the vehicle manufacturer's instructions.
 - The coolant circuit must then be vented.
- Operation or the after running of the heater may only be stopped in an emergency (see "EMERGENCY OFF" Page 7) by interrupting the battery current (risk of heater overheating).


Special tool


AMP release tool

The AMP release tool is used to unclip push-on sleeves from a connector housing.

This release tool can be ordered directly from Eberspächer GmbH & Co. KG.

- For Micro Timer
- Order No. 206 00 205
- For Junior Power Timer
- Order No. 206 00 204







Parts list

- Heat exchanger, complete with combustion chamber
- 2 Combustion chamber cover
- 3 Seal combustion chamber
- 4 Combustion air fan
- 5 Seal
- 6 Control box
- Glow plug
- Connection cable for glow plug
- Fixing nut M4
- 10 Lining
- 11 Intake hood
- Shell holder 12
- Upper jacket shell 13
- Grommet (glow plug)
- 15 Grommet (Rotary valve)
- 16 Grommet (cable harness)
- Lower jacket shell 17
- 18 Heat shield
- 19 Outlet hood
- Combination sensor (flame / overheating sensor)
- 21 Combination sensor retaining clips
- 22 Sealing, flange
- Single-thread screw B 3,5 x 9,5 Z1 DIN 7981 ZN12FF
- Single-thread screw B 3,5 x 13 Z1
- Fillister head bolt M5 x 20 Z3 DIN 7895 4.8 ZN8
- 26 C-Clip single-thread nut
- 27 DUO-Clip, (retaining clips)
- 28 Screw M5 x 25, TORX DIN 7500 C
- Fillister head bolt M5 x 16 Z3 DIN 7895 4.8 ZN8

Repair step 1 Dismantle / assemble glow plug (Figure 1)

- Remove large angular rubber grommet.
- Unscrew M4 fixing nut of the connection cable and screw out the glow plug using a SW 19 socket spanner.
- Install in the reverse order.
 Glow plug torque 20^{±2} Nm.
 Connection cable nut torque 1.4 Nm.

Please note!

- With the glow plug dismantled, visually check the lining of the installed glow plug support for dirt. If the lining is highly soiled and its surface closed, renew the lining (see repair step 2).
- Ensure the rubber grommet sits securely and tightly!




Figure 1

- ① Glow plug
- Fixing nut for connection cable

Repair step 2 Dismantle / assemble lining

(Figure 2)

- Repair step 1, dismantle / assemble glow plug.
- Use long-nose pliers to pull the lining out of the support from above.
- · Clean the support by blowing it with compressed air.
- If necessary, carefully push through a wire.
- Carefully install the new lining. No special tools required.




Figure 2

① Lining

Repair step 3 Dismantle / assemble control box

(Figure 3)

- Unscrew the 4 fixing screws of the intake hood.
- Remove intake hood.
- Check inserted seal for damage, replace if necessary.
- · Unscrew the fixing screw of the control box.
- Remove grommet from the upper jacket shell.
- Press together the retaining clamps.
- Remove the control box from above.
- Remove all connection cables from the control box. (Note the position of the cables). The control box can now be removed.
- Install in the reverse order.
 Torque for intake hood fixing screws 4.0+0.5 Nm.
 Torque for control box fixing screw 1.75±0.25 Nm.

Please note!

When assembling the control box ensure that all the connection cables have been inserted in the control box (non-reversible).




Figure 3

- Intake hood fixing screws
- Control box fixing screw
- (3) Control box
- Retaining clamp
- (5) Grommet



Repair step 4 Dismantle / assembly combination sensor (overheating / flame sensor) (Figure 4 – 6)

- Repair step 3, dismantle / assemble control box.
- Unscrew the 4 fixing screws of the outlet hood and remove outlet hood.
- Unscrew the 12 fixing screws of the upper jacket shell and remove the upper jacket shell.
- Use a screwdriver to remove both DUO-clip (retaining clips) at the heat shield and remove the heat shield.
- Pull off the retaining clip of the combination sensor (flame / overheating sensor) from above.
- Install in the reverse order.
 Torque for outlet hood fixing screws 1.45 ±0.5 Nm.
 Torque for upper jacket shell fixing screws 1.45 ±0.5 Nm.






Figure 4

- ① Outlet hood fixing screws (B 3.5 x 13) (opposite side of unit is mirror image)
- ② Fixing screws of upper jacket shell (10 No. B 3.5 x 9.5 and 2 No. B 3.5 x 13)



Combination sensor (flame / overheating sensor)

Circuit diagram for combination sensor (overheating sensor / flame sensor)







Figure 5

- DUO-clip (retaining clips)
- (2) Heat shield

Check combination sensor

The external temperature sensor must be checked using a digital multimeter. If the resistance value does not match the curve in the diagram, replace the combination sensor.



Please note!

Note the max. temperature of 320° for the test.




Table of overheating sensor values

Temperature °C	Resistance k Ω	min.	max.
-40		1597.00	1913.00
-20		458.80	533.40
0		154.70	175.50
20		59.30	65.84
40		25.02	28.04
60		11.56	13.16
80		5.782	6.678
100		3.095	3.623
120		1.757	2.081
140		1.050	1.256
160		0.6554	0.792
180		0.4253	0.5187
200		0.2857	0.3513

Table of flame sensor values

Temperature °C	Resistance Ω	min.	max.
-40		825.90	859.60
0		980.00	1020.00
40		1132.30	1178.50
80		1282.80	1335.10
120		1431.50	1489.90
160		1578.30	1642.80
200		1723.40	1793.70
240		1866.60	1942.80
280		2008.10	2090.00
320		2147.70	2235.40

7

Repair step 5 Dismantle / assemble combustion air fan (Figure 7 – 11)

- Repair step 3, dismantle / assemble control box.
- Unscrew the 4 fixing screws of the outlet hood and remove outlet hood.
- Unscrew the 12 self-tapping screws of the upper jacket shell and remove the upper jacket shell.
- · Remove flange seal.
- Unscrew the 2 self-tapping screws of the lower jacket shell at the shell holder and remove the lower jacket shell.
- Unscrew the 4 screws of the shell holder.
- Unscrew the 5 screws of the combustion air fan.
- · Remove the combustion air fan.
- Install in the reverse order.

Torque for outlet hood fixing screws 1.45 $^{\pm0.5}$ Nm. Torque for upper and lower jacket shell fixing screws 1.45 $^{\pm0.5}$ Nm.

Torque for shell holder fixing screws $2.5\,^{\pm0.5}$ Nm. Torque for combustion air fan fixing screws $4.0\,^{\pm0.5}$ Nm.

Please note!

Always renew the seal between the combustion air fan and the heat exchanger.




Figure 7

- ① Outlet hood fixing screws (B 3.5 x 13) (opposite side of unit is mirror image)
- 2 Fixing screws of upper jacket shell (10 No. B 3.5 x 9.5 and 2 No. B 3.5 x 13)




Figure 8

- ① Shell holder
- ② Flange seal
- (3) Fixing screws of lower jacket shell(2 No. B 3.5 x 13, opposite side of unit is mirror image)




Figure 9 Fan wheel removed for improved view.

- (fillister-head screw M5 x 20)
- Shell holder




Figure 10 Fan wheel removed for improved view.

 Fastening screws of combustion air fan (fillister-head screw M5 x 20)




Figure 11

- ① Combustion air fan
- ② Heat exchanger

Repair step 6 Replace the combustion chamber cover seal (Figure 12)

- Repair step 5, dismantle / assemble combustion air fan.
- Unscrew the 4 screws of the combustion chamber cover.
- Remove the combustion chamber cover.
- Remove seal, clean seal surfaces if necessary, install new seal.
- Install in the reverse order.
 Torque of combustion chamber cover fixing screws 3.5^{+0.5} Nm.

Please note!

Ensure the combustion air duct sits correctly in the combustion chamber cover.

Tighten the fixing screws "crosswise" (i.e. diagonally opposite screws, one after the other).




Figure 12

- ① Combustion air duct
- ② Sea
- ③ Combustion chamber cover
- 4 Fixing screws



Check fuel supply

Before measuring the fuel quantity, check the following points in the fuel supply.

- Check the screen in the metering pump.
- · Check the laying of the fuel pipes.
- · Check fuel pipes for leaks.
- · Check and tighten the hose connections.
- Is the fuel removal installed according to the details in the technical description?

Measuring the fuel quantity

1. Preparation

Remove the fuel pipe at the heater and insert a measuring cylinder (size 25 ml).

Switch on the heater, if the fuel is uniformly pumped (begins approx. 60 sec after being switched on), the fuel pipe is full and vented.

Switch off heater and empty measuring cylinder.

Please note!

For precise fuel measurement at least 11 volt and 22 volt or maximum 13 volt and 26 volt should be applied to the control box during the measurement.

2. Measurement

Switch on heater.

The fuel begins to be pumped approx. 60 sec after switching on the heater.


During the measurement, hold the measuring cylinder at the level of the heater.

After approx. 90 sec of the fuel being pumped it is automatically switched off. Switch off heater! * Read off the quantity of fuel in the measuring cylinder.

If the measured fuel quantity lies outside the values given below, the metering pump must be replaced.

Heater	AIRTRONIC L - B5	AIRTRONIC L - D5
min. (ml)	14	8
max. (ml)	18	10

* Important, as otherwise fuel will be pumped again after approx. 120 sec.



Sketch 7

- Heater
- ② Metering pump
- ③ Measuring cylinder (size 25 ml)
- 4 Fuel pipe (disconnect at heater and insert in a measuring cylinder).

Parts list circuit diagrams AIRTRONIC L / AIRTRONIC L – ADR / ADR99

1.1 1.2 1.5	Burner motor Glow plug Overheating and flame sensor
2.1 2.2 2.7	Control box Metering pump Main fuse 12 volt = 25 A
2.7.1	24 volt = 20 A Fuse, actuation (5 A)
5.1 5.2.1	Battery Battery operating switch (operation, e.g. controlled by the ignition lock) d)
5.2.2	Battery isolating switch (EMERGENCY OFF function for ADR / ADR99) d)
5.3 5.3.1 5.5	Auxiliary drive (HA+) Auxiliary drive switch Generator terminal (D+)

- Control units and room temperature sensor connected according to the "control units" circuit diagram.
 - ge Switch-on signal (- S+)
 brws Reference signal sensor
 grrt Temperature (setpoint)
 - blws Diagnosis
 - br Power supply, negative (terminal 31)
 wsrt Switch off the anti-theft alarm system (ADR / ADR99 – feedback signal for timer)
 - gr Temperature (actual value)
 - rt Power supply, positive (terminal 30)
- b) Option
 - Fresh air fan
 - Vehicle fan control
- c) ADR / ADR99

Dangerous goods transporter in the area of the utility vehicle (e.g. tanker)

d) If only one switching element is used for items 5.2.1 and 5.2.2, it is important to ensure that on activating the "open the battery isolating switch" function (EMERGENCY OFF function in ADR / ADR99 or similar), the switch always breaks contact immediately (regardless of the heater condition) and all the heater's circuits are disconnected from the battery.

Please note!

- Insulate unused cable ends.
- Connectors and bush housings are shown from the cable inlet side.

Parts list circuit diagram control units / control units – ADR / ADR99

Tanana anatana arang (arang 1 arang 1 arang 1

2.15.1	Temperature sensor (room temperature)
2.15.9	Temperature sensor (outside temperature)
0.4.0	
3.1.9	Changeover switch "heat / ventilate"
3.1.16	Radio remote control button
3.1.17	Mini controller AIRTRONIC
3.1.18	Button CALLTRONIC
3.2.8	Module timer (ADR / ADR99 – potentiometer)
3.2.12	Timer, mini – 12 / 24 volt
3.2.14	Lighting, mini timer – 12 volt only
3.3.6	Radio remote control stationary part TP41i
3.3.7	Radio remote control stationary part TP5
3.3.8	Remote control CALLTRONIC
3.8.3	Antenna
3.9.1	Diagnosis, JE diagnosis

- a) Connection of control units at the heater
 - rt Power supply, plus terminal 30ge Switch-on signal S+
 - gr Temperature actual value
 - wsrt Switch off the anti-theft alarm system (ADR / ADR99 feedback signal for timer)
 - br Power supply, minus terminal 31
 - blws Diagnosis
 - grrt Temperature setpoint
 - brws Ground connection for external temperature sensor and temperature setpoint
- b) Terminal 15 necessary for connection TP4i
- c) Lighting, terminal 58
- d) Connection, diagnostic unit
- e) Connection, external temperature sensor
- g) Connection, external heating button
- h) Connection, radio remote control TP4i
- j) Connection, temperature sensor (outside temperature)
- Connection, change-over switch "heat / ventilate" (option) Initial operation: Activate changeover switch "heat / ventilate" then switch on the heater.
- z) Lighting, terminal 58

Cable colours circuit diagrams


black WS white white / red wsrt = rt red yellow ge green an vi violet br brown brws = brown / white

gr = grey grrt = grey / red bl = blue blws = blue / white

i = purple


Please note!

- Insulate unused cable ends.
- Connectors and bush housings are shown from the cable inlet side.






AIRTRONIC L circuit diagram - 12 volt / 24 volt




Parts list Page 32


25 2361 00 98 01 A

Circuit diagram for control units





25 2069 00 97 01 C




Parts list Page 32


25 2069 00 97 03 B



Circuit diagram for control units




Circuit diagram for control units




25 2069 00 97 02 A




Circuit diagram for control units




Circuit diagram for control units








Circuit diagram AIRTRONIC L - ADR / ADR99 - 12 volt / 24 volt



39

Circuit diagram control units - ADR / ADR99



25 2069 00 96 01 B

7 Service

Certifications

The high quality of Eberspächer's products is the key to our success.

To guarantee this quality, we have organised all work processes in the company along the lines of quality management (QM). Even so, we still pursue a large number of activities for continuous improvement of product quality in order to keep pace with the similarly constantly growing requirements made by our customers.

All the steps necessary for quality assurance are stipulated in international standards.

This quality is to be considered in a total sense. It affects products, procedures and customer / supplier relationships.

Officially approved public experts assess the system and the corresponding certification company awards a certificate.

Eberspächer has already qualified for the following standards:

Quality management in accordance with DIN EN ISO 9001:2000 and ISO/TS 16949:1999

Environmental management system in accordance with DIN EN ISO 14001:1996

Disposal

Disposal of materials

Old devices, defect components and packaging material can all be separated and sorted into pure-grade factions so that all parts can be disposed of as required in an environment-friendly manner recycled where applicable.

Electric motors, controllers and sensors (e.g. temperature sensors) are deemed to be "electronic scrap".

Dismantling the heater

The heater is dismantled according to the repair stages in the current troubleshooting / repair instructions.

Packaging

The packaging of the heater can be kept in case it has to be sent back.

EC Declaration of Conformity

With regard to the following products

Heater type AIRTRONIC L

we herewith confirm that it conforms with the prime safety requirements stipulated in the directives of the EU Council for harmonisation of the legal regulations of the member states with regard to electromagnetic compatibility (89 / 336 / EEC). This declaration applies to all heaters manufactured according to the *AIRTRONIC* L production drawings, which are an integral part of this declaration.

The following standards / directives have been used to assess the product with regard to electromagnetic compatibility:

- EN 50081 1 Basic form interference emission
- EN 50082 1 Basic form of interference immunity
- 72 / 245 / EEC Modification status 95 / 54 / EC interference suppression in motor vehicles.

7 Service

Representatives abroad

Argentinien Argentina Argentine

AGCO Argentinia S. A. Valentin Gomez 577 1706 Haedo RA - Pcia. Buenos Aires Tel. 0054 / 1 - 483 32 01 Fax. 0054 / 1 - 483 32 37

Champion S. A. Av. Cordoba 2756 al 58 RA - 1187 Buenos Aires Tel. 0054 / 1 - 962 16 21 Fax. 0054 / 1 - 962 16 27

für Bootsheizungen for boat heaters / pour bateau chauffages

Trimer S. A. P.O. Box 206 RA - 1425 Buenos Aires Tel. 0054 / 11 47 77 45 77 Fax. 0054 / 11 47 77 45 88

Belgien u. Luxemburg Belgium and Luxembourg Belgique et Luxembourg

Eberspächer B. V. B. A. Brixtonlaan 27 Industriezone Zuid B - 1930 Zaventem Tel. 0032 / 2 - 720 97 35 / 36 Fax. 0032 / 2 - 721 27 00

Chile Chili

für Bootsheizungen for boat heaters / pour bateau chauffages Nauticentro Ltda. Tomas Moro 135 Las Condes - Santiago Tel. 0056/2 - 201 49 66 Fax. 0056/2 - 201 56 35

Dänemark Denmark Danemark

Robert Bosch A / S Telegrafvej 1 DK - 2750 Ballerup Tel. 0045 / 44 - 89 89 89 Fax. 0045 / 44 - 89 86 80

Estland Estonia Estonie

Hesyco Group OÜ Mäo 72751 Järvamaa Tel. 00372 / 38 48 890/891 Fax. 00372 / 38 48 892

Finnland Finland Finlande

Wihuri Oy Autola Manttaalitie 9 SF - 01510 Vantaa 51 Tel. 0035 / 89 - 82 58 51 Fax. 0035 / 89 - 82 58 52 07

Frankreich France France

Eberspächer S. A. S. Z.A.C. la Clé Saint Pierre 3 rue Blaise Pascal F - 78996 Elancourt Cedex Tel. (0033) 1 - 30685454 Fax. (0033) 1 - 30685455

Griechenland Greece Grèce

SYSTEMS S. A. 78, Pireos Avenue GR - 18346 Moschato - Athen Tel. 0030 / 1 - 4 81 09 58 Fax. 0030 / 1 - 4 81 13 32

Großbritannien Great Britain Grande-Bretagne

Eberspächer UK Ltd. Headlands Business Park Salisbury Road, Ringwood GB - Hampshire BH 243 PB Tel. 0044 / 1425 - 48 01 51 Fax. 0044 / 1425 - 48 01 52

Italien Italy Italie

Ofira Italiana SPA.
Via Eritrea 20 F
I - 25 126 Brescia
Tel. 0039 / 030 37931
Fax. 0039 / 030 45188

Iran Iran Iran

Overseas Techno Trading Co. No. 4 GF, 17th Bucharest Ave., Argentina Sq., Tehran 15138 Tel. 0098 / 21 - 87 131 16/17 Fax. 0098 / 21 - 87 125 76

Japan Japan Japan

White House Co., Ltd. 412 Nakashua-Cho, Tenpan-Hu Nagoya 468 - 0096 Tel. 0081 / 52 835 56 11 Fax. 0081 / 52 835 56 12

Kanada Canada Canada

Espar Products Inc. 6435 Kestrel Road CDN - Mississauga Ontario L5T / 1Z8 Tel. 001 / 905 - 670 09 60 Fax. 001 / 905 - 670 07 28

Lettland Latvia Lettonie

Trans Baltic Trading Corporation Maskavas iela 449 LV - 1063 Riga Tel. 00371 / 2 - 266 323 Fax. 00371 / 7 - 187 967

Litauen Lithuania Lituanie

Tradcon Ltd.
Paneriu 51
LIT - 2055 Vilnius
Tel. 00370 / 2 - 33 44 30
Fax. 00370 / 2 - 23 35 37

Republik Moldova Republic Moldavia République Moldavie

TC - IUSTINIAN 140 Hinchesti Str., of.9 MD - 2070 Kishinev Tel. +3732 / 727883, 738710 Fax. +3732 / 727883

7 Service



Representatives abroad

Niederlande Netherlands Pays-Bas

Eberca B. V. Benjamin Franklinstraat 10 Postbus 1594 NL - 3260 BB Oud - Beijerland Tel. 0031 / 1866 - 2 19 55

Fax. 0031 / 1866 - 2 18 18

Norwegen

Norweger Norway Norvège

Robert Bosch Norge A / S Postbox 629 N - 1411 Kolbotn Trollasveien 8 N - 1414 Trollosen Tel. 0047 / 66 - 81 70 00 Fax. 0047 / 66 - 81 71 86

Österreich Austria Autriche

Eberspächer Ges.m.b.H. Richard-Strauss-Str. 4 A - 1232 Wien Tel. 0043 / 615 47 47 0 Fax. 0043 / 615 47 47 42

Polen Poland Pologne

Eberspächer Sp.zo.o Wysogotowo K. Poznania ul. Okrezna 17 PL- 62081 Przezmierowo Tel. 0048 / 61 - 816 18 50 Fax. 0048 / 61 - 816 18 60

Russland Russia Russie

Company OKMA Kashirskoye shosse 13a RUS - 115230 Moskau Tel./Fax. 007 / 095 - 111 - 90 95

Schweden Sweden Suède

Svenska Eberspächer AB Box 2103 S - 12823 Skarpnäck Tel. 0046 / 86 83 11 00 Fax. 0046 / 87 24 90 40

Schweden Sweden Suède

Ardic Heating Systems AB Kardonvägen 34 S - 46138 Trollhäten Tel. 0046 / 520-490-800 Fax. 0046 / 520-490-890

Schweiz Switzerland Suisse

Technomag AG Fischermättelistr. 6 Ch - 3000 Bern - 5 Tel. 0041 - 31 379 81 21 Fax. 0041 - 31 379 82 50

Spanien – Portugal Spain – Portugal Espagne – Portugal

Pedro Sanz Clima S.L Avda. Ingeniero Alfonso Peña Boeuf, 10 E - 28022 Madrid Tel. 00349 / 1 - 748 07 85 Fax. 00349 / 1 - 329 42 31

Tschechien Czech Republic République Echèque

Eberspächer spol.sr.o. Joremiàsova 870 - areál IPS CZ - 15543 Praha 5 Tel. 00420 / 2 - 652 05 48/49/50 Fax. 00420 / 2 - 652 05 37

Türkei Turkey Turquie

OSCA Otomotiv Ltd.
Org.Sanayi Sitesi Dolapdere Koop.
3 Ada No: 2
TR - Ikitelli / Istanbul
Tel. +90 212 - 549 86 31
Fax. +90 212 - 549 33 47

Ungarn Hungary Hongrie

Austropannon KFT Fö ut 96 H - 9081 Györujbarat Tel. 0036 / 96 - 54 33 33 Fax. 0036 / 96 - 45 64 81

Ukraine Ukraine Ukraine Geruk K ul. Vernigory 15 257008 Tscherkassy Tel. 0038 / 04 72 63 87 47 Fax. 0038 / 04 72 63 87 47

USA USA Etats-Unis

Espar Tech Center 9675 Harrison Road Suite 102 Romulus, Michigan 48 174 Tel. 001 / 734 - 947 - 39 00 Fax. 001 / 734 - 947 - 72 98

Weißrussland Belarus Biélorussie

ZAO Belvneshinvest
UI. Wostochnaja 129 / 102 - 104
BY. 220 113 Minsk
Tel. 00375 / 172 317 294
Fax. 00375 / 172 317 481

8 Index

Index

Keyword	Page
Accident preventionAdapter cable11,	12, 16
Assembly drawing C Cancel the control box lock 13, 15, Certifications Check temperature sensor Circuit diagram S Combination sensor Combustion air fan Combustion chamber cover Control and safety devices Control box	16, 17 41 8 32 - 40 27 29 30 7
Customer service program Cutaway view Diagnostic unit Disposal	5 11, 12 41
Emergency stop Explosion drawing Fan speed Fault code	24
Fault description Fault diagnosis Faults Flame sensor Fuel metering pump Fuel supply Function Functional description	11 9 27 31 31 5 - 7
Glow plug	4
Heating mode	

Keyword
Liability claim
M Metering pump31 Module timer11, 14
Overheating sensor27
P Parts list
Q Quality management41
R Regulations 4 Repair instructions 23 - 31 Representatives abroad 42, 43 Representatives 42, 43
Safety devices 7 Safety information 2 Service 41 - 43 Statutory regulations 2
T Technical data 8 Testing equipment 1 TP5 radio remote control 11, 17 Troubleshooting 9 - 22
V Ventilating mode

8 Index



List of abbreviations

ADR

European agreement about the international transport of dangerous goods on the road.

ADR99

Dangerous goods regulations for France.

EC type-approval

Permit awarded by the Federal Vehicle Office for the production of a heater for installation in motorised vehicles.

EMC Directive

Electromagnetic compatibility.

JE-partner

J. Eberspächer partner.

PME

Biodiesel as per DIN V 51606.